

## USER INSTRUCTIONS VITROSTATIC

### ATTENTION:

- n Do not apply the film at or below a temperature of 5 °C.
- n The film is only suitable for indoor use

### STEP 1



Carefully clean the surface of the section to be applied, making sure it is dust-free and smooth. Cut the film to a slightly larger size than the area to be covered. Spray the window with water. Peel the protective layer off the film.

### STEP 2



Apply the film to the window, making sure to position it carefully. Wet the outer surface of the film to prevent scratching.

### STEP 3



Use a window wiper to smooth out the film starting in the middle in order to remove air and moisture from in between the window and the film.

### STEP 4



Remove excess film using a sharp knife along a ruler or straight edge, and then smooth over.